

# CoverTec Products

## Key Steps to applying NanoPrime and VinylDiamond

### Stripping Cleaning

Pick-up the stripping solution with a wet vacuum, automatic scrubber or clean mop. Rinse with freshwater and allow floor to dry thoroughly prior to applying any NanoPrime.

### Priming and Coating

- Nano Prime the floor:
  - Stir container for 1 minute to make sure all contents are evenly dispersed
  - Pour contents into mop container or pump spray container.
  - Spray a little NanoPrime on the floor and saturate micro pad
  - Spray a line of NanoPrime material onto the floor
  - Spread THIN and EVEN 1<sup>st</sup> coat. It will dry quickly. Do NOT OVER-APPLY or OVER-WORK
  - Work in small areas
  - Let dry for 5- 10 minutes
  - Burnish ( 2000 RPM) 1st coat with a WHITE POLISHING PAD
  - Apply 2<sup>nd</sup> coat using same techniques as above. Will use even less product
  - Let dry for 5 -10 minutes
  - Burnish 2<sup>nd</sup> coat with a WHITE POLISHING PAD
- Apply VINYLDIAMOND
  - Dust mop floor
  - Put product into mop or pump spray container
  - Spray a little VinylDiamond on the floor and saturate micro pad
  - Spray a line of VinylDiamond material onto the floor
  - 1<sup>st</sup> Coat - Working in SMALL AREAS – 4' x 5' and spread with micro pad
    - THE TRICK IS TO SPREAD THE PRODUCT **THIN AND EVENLY** WITH THE MICROPAD. DO NOT KEEP WIPING OVER IT. IT GOES DOWN **THIN** AND DRIES FAST SO IF YOU OVER WORK IT YOU WILL GET STREAKS. REMEMBER WORK IN SMALL AREAS
  - Wait 5-10 minutes and then burnish 1<sup>st</sup> coat. . Use an AQUA PAD. Remember do not over burnish. Walk burnisher slowly over the area.
  - 2<sup>nd</sup> Coat – Apply same as 1<sup>st</sup> coat above
  - Wait 5-10 minutes and then burnish 2<sup>nd</sup> coat. Use an AQUA PAD. Remember do not over burnish. Walk burnisher slowly over the area.
  - YOU ARE DONE!



**Microfiber Bucketless System**



**Aqua Pad**



**Microfiber Damp Mopping Pad**



**3m Microfiber Pad**

Any questions please give us a call to 888-994-0727. Or visit us on our YouTube Chanel  
[www.tec@covertectproducts.com](http://www.tec@covertectproducts.com)