



CoverShield U140 Cleaning & Maintenance Instructions

Based on foot and vehicular traffic, floor should be swept clean with broom or a microfiber dusting pad. In a workshop environment or where there is heavy vehicular traffic, floor surface should be mopped daily or cleaned with a floor machine using a neutral cleaning solution.

The most critical procedure for keeping the floor clean is to AGITATE the floor with GlossClean solution diluted with water using a white pad or soft brush followed by EXTRACTION.

The agitation suspends the soil in the water/cleaning solution and the extraction removes the soil from the flooring surface. Removal of the soil prevents it from settling back onto the floor. The AGITATION can be done in many ways including:

- 1) manually with soft brush or
- 2) with a 175-RPM floor machine with a soft brush or white pad or
- 3) by employing an auto scrubber with soft brushes or pads. Use a soft brush manually or with a floor machine to clean.

U140 with CoverGrip. DO NOT CLEAN U140/CoverGrip System WITH A PAD, AS IT WILL MORE QUICKLY WEAR OFF THE COVERGRIP AGGEGATE

EXTRACTION should immediately follow agitation. Extraction can be done in many ways including:

- 1) a high quality, commercial wet vac with squeegee or wand or
- 2) an auto scrubber or
- 3) a portable or truck mounted rinse and reclaim system.

How To Recoat/Repair:

Five years plus (depending on traffic): scrub the surface using an auto scrubber fitted with a black pad.

Clean surface with GlossClean neutral cleaner product. Re-apply 1–2 coats of U140.

U140 Maintenance Instructions Continued

To spot repair: if deep scratches or extreme chemical removes the finish, follow these steps to repair the spot.

1. Sand area to feather out damaged area.
2. Use neutral cleaner or rubbing alcohol to neutralize sanded area.
3. Re-apply on the clean spot.
4. Re-coat surface with 2–3 coats of U140 product.
5. Wait 3 to 6 hours minutes between each coat.
6. Allow 24 hours before vehicular traffic.

END OF SECTION